DX8200A-3002

QUICK REFERENCE GUIDE

NOTE

This manual illustrates a typical Local Lonworks network application. For more details refer to the DX8200A Reference Manual available on the CD. For complete scanner configuration using the Genius™ configuration program refer to the Help On Line.

821001255 (Rev. F)

UPDATES AVAILABILITY

UK/US The latest drivers and documentation updates for this product are available on Internet. Log on to: **www.automation.datalogic.com**

I Su Internet sono disponibili le versioni aggiornate di driver e documentazione di questo prodotto. Collegarsi a: **www.automation.datalogic.com**

F Les versions mises à jour de drivers et documentation de ce produit sont disponibles sur Internet. Cliquez sur : **www.automation.datalogic.com**

D Im Internet finden Sie die aktuellsten Versionen der Treiber und Dokumentation von diesem Produkt. Adresse : **www.automation.datalogic.com**

E En Internet están disponibles las versiones actualizadas de los drivers y documentación de este producto. Dirección Internet : **www.automation.datalogic.com**

SERVICES AND SUPPORT

Datalogic provides several services as well as technical support through its website. Log on to **www.automation.datalogic.com** and click on the links indicated for further information:

- **PRODUCTS**

  Search through the links to arrive at your product page which describes specific Info, Features, Applications, Models, Accessories, and Downloads including the Genius™ utility program, which allows device configuration using a PC. It provides RS232 and Ethernet interface configuration.

- **SERVICE**
  - **Overview -** Warranty Extensions and Maintenance Agreements
  - **Sales Network-** Listing of Subsidiaries, Repair Centers, Partners
  - **Helpdesk**
  - **Material Return Authorization**

LEGAL NOTICES

© 2005 - 2012 Datalogic Automation S.r.l. ◆ ALL RIGHTS RESERVED. ◆ Protected to the fullest extent under U.S. and international laws. Copying, or altering of this document is prohibited without express written consent from Datalogic Automation S.r.l.

Datalogic and the Datalogic logo are registered trademarks of Datalogic S.p.A. in many countries, including the U.S.A. and the E.U.

Genius, PackTrack, ACR, ASTRA, CD SQUARE and ID-NET are trademarks of Datalogic Automation S.r.l. All other brand and product names mentioned herein are for identification purposes only and may be trademarks or registered trademarks of their respective owners.

Datalogic shall not be liable for technical or editorial errors or omissions contained herein, nor for incidental or consequential damages resulting from the use of this material.

DX8200A-3002 GENERAL VIEW



Figure A

1 Laser Beam Output Windows
2 Mounting Slots
3 Laser Safety Label
4 Mounting Reference Label

Figure B

1 Programming Keypad
2 Power On LED (Green)
3 Phase On LED (Yellow)
4 Encoder LED (Yellow)
5 TX Data LED (Green)
6 Network LED (Red)
7 LCD Display

Figure C

1 Lonworks 17-pin Male Connector
2 Lonworks 17-pin Female Connector

CONNECTIVITY



Large Synchronized Network with DX8200A and DS8100A Scanners



Example Large Synchronized Network Reading Station



Redundant Reading Station Layout with DX8200A and DS8100A Scanners



Example Redundant Reading Station

ELECTRICAL CONNECTIONS

Two 17-pin connectors provide access to the scanner's local Lonworks network used for both input and output connections to build a multi-sided or omni-station system.

17-pin Lonworks Connector Pinout

Pin	Name	Function
A1	GND	Supply voltage (negative pin)
A2	VS	Supply voltage 20 to 30 Vdc (positive pin)
1	CHASSIS	Cable shield A - internally connected by capacitor to chassis
2	n.c.	Not connected
3	CHASSIS	Cable shield B - internally connected by capacitor to chassis
4	TXAUX	Transmit data of auxiliary RS232 (referred to SGND)
5	SGND	Signal ground (connected to GND)
6	RXAUX	Receive data of auxiliary RS232 (referred to SGND)
7	VS_I/O	Supply voltage of I/O circuit
8	Lon A+	Lonworks a line (positive pin)
9	Lon A-	Lonworks a line (negative pin)
10	Lon B+	Lonworks b line (positive pin)
11	Lon B-	Lonworks b line (negative pin)
12	SYS_I/O	System signal
13	SYS_ENC_I/O	System signal
14	Reserved	Internally connected
15	Ref_I/O	Reference voltage of I/O circuit



Male - Input



Female - Output

17-pin Local Lonworks Connectors

APPENDIX

TECHNICAL FEATURES

ELECTRICAL FEATURES		
Supply Voltage	20 to 30 Vdc	
Power Consumption	24 W typical	
	1.5 to 1.0 A max. (including startup current)	
Communication Interfaces	**Auxiliary**	**Baud Rate**
	RS232	1200 to 115200
	Other	
	Lonworks	1.25 Mb/s
OPTICAL FEATURES		
Light Receiver	Avalanche photodiode	
Wavelength	630 to 680 nm	
Safety Class	Class 2 - EN60825-1; Class II - CDRH	
Light Source	Up to 4 semiconductor laser diodes	
Laser Control	Security system to turn laser off in case of motor slow down	
READING FEATURES		
Scan Rate	≤ 1000 scans/s (500 per leg)	
Maximum Resolution Max. Reading Distance Max. Reading Width Max. Depth of Field	(see reading diagrams on page 10)	
USER INTERFACE		
LCD Display	2 lines by 20 characters LCD	
Keypad	3 keys	
LED Indicators	Power On (green) Phase On (yellow) Encoder (yellow) TX Data (green) Network (red)	
SOFTWARE FEATURES		
Readable Codes	Interleaved 2/5 Code 39 Standard Codabar Code 128 GS1-128 (ex EAN 128) Code 93 (standard and full ASCII) EAN/UPC (including Add-on 2 and Add-on 5) GS1 DataBar (including Limited and Expanded)	
Code Selection	Up to 10 codes during one reading phase	
Operating Modes	PackTrack™	
Configuration Modes	Genius™ utility program	
Parameter Storage	Non-volatile internal FLASH	

ENVIRONMENTAL FEATURES	
Operating Temperature Storage Temperature Humidity	0° to +50 °C (+32° to +122 °F) -20° to +70 °C (-4° to +158 °F) 90% non condensing
Ambient Light Immunity	20000 lux
Vibration Resistance EN 60068-2-6 2 hours on each axis	Frequency range from 5 to 150 Hz; Constant displacement 3 mm pk-pk from 5 to 9 Hz; Constant acceleration 0.5 g from 9 to 150 Hz;
Shock Resistance EN 60068-2-27 3 shocks on each axis	30 g; 11 ms
Protection Class EN 60529	IP65*
PHYSICAL FEATURES	
Mechanical Dimensions	470 x 300 x 141 mm (18.50 x 11.81 x 5.55 in)
Weight	about 11 kg (24 lbs 3 oz)

* IP65 cables and connectors required (CAB-850x or BTK-8500).

ACCESSORIES

Name	Description	Part Number
Power Supply		
PWO-480	Power and Connect System 480W	93ACC1767
Cables and Terminators		
BTK-8100	Bus Terminator Kit (5 pcs)	93ACC1090
BTK-8500	IP65 Terminator Kit (2 pcs)	93A051286
CAB-8100	10 wire shielded cable D 9.5 mm – 50 m	93ACC1120
CAB-8101	17-pin scanner/scanner connection cable 1.2 m	93A051020
CAB-8102	17-pin scanner/scanner connection cable 2.5 m	93A051030
CAB-8105	17-pin scanner/scanner connection cable 5 m	93A051040
CAB-8501	IP65 Cable Fam 8K 1,2 m	93A051283
CAB-8502	IP65 Cable Fam 8K 2,5 m	93A051284
CAB-8505	IP65 Cable Fam 8K 5 m	93A051285
Sensors		
S30	Photocell Kit	93ACC1782
MEP-593	Photocell kit – PNP (PH-1)	93ACC1791
MEP-543	Photocell Kit – NPN	93ACC1728
OEK-2	Optical Encoder Kit + 10 m cable + Spring	93ACC1770
OEK-1	Optical Encoder Kit + 10 m cable	93ACC1600
Miscellaneous		
PLL-8000	Optocoupled PLL device	93ACC1280
FS-1	Frame Shaper (8 pcs)	93ACC1750

MECHANICAL INSTALLATION

DX8200A-3002 can be installed to operate in any position. There are 4 slots (dia. 8.5 mm) on the sides of the scanner for mounting. The diagram below can be used for installation; refer to the Reading Diagrams for correct positioning of the scanner with respect to the reading zone and scanner orientation.



DX8200A-3002 Overall Dimensions

WARNING

When installing several scanners, take care to position them correctly so that no laser beam enters the reading window perpendicularly and at the same level of the output beam of the other scanners. This condition could occur more frequently for side mounted applications. If these precautions are not followed, it may occur that the laser of the blinded scanner starts blinking due to an internal circuit which temporarily turns the laser off when detecting a power anomaly. To resolve this problem, it is sufficient to slightly change the inclination and position of one of the two scanners involved.

Mounting Stops



X-axis Reference Point Stops

Two washers and two spacers are provided in the DX8200A package to create two stops which can be used to facilitate DX8200A mounting and positioning. Create each stop by mounting a washer and spacer to the Reading Station Frame using Bosch T-bolts and nuts. See the figure above.

- During initial mounting, affix the stops in approximation to the mounting position. The weight of the DX8200A can rest against this reference while the mounting bolts are being set. This avoids having to hold and maneuver the scanner (especially for vertical side mounted positions) while simultaneously affixing it to the frame.

- Once the scanner is correctly positioned for PackTrack, fix the stops against the scanner. The stops remain fixed to the station frame so that the scanner can be replaced without having to recalibrate the PackTrack coordinates. Referring to the figure above, the stop provides a reference point for the X-axis while the scanner should be centered on the frame to have a fixed reference for the Y-axis.

SCANNER DIRECTION

The different scanner orientations are illustrated in the following figures:



DX8200A-3002 Scanner Direction 0° (Forward)



DX8200A-3002 Scanner Direction 180° (Reverse)

READING DIAGRAMS

Note: x = 0 and z = 0 correspond to the edge of the DX8200A-3002 scanner as shown in the figure below.

DX8200A-3002 (0.50 mm/20 mils)





CONDITIONS

Code = Interleaved 2/5 or Code 39
PCS = 0.90

COMPLIANCE

See the DX8200A Reference Manual for the Declaration of Conformity.

LASER SAFETY



Figure D

(1) Warning and Device Class Label (2) Device Identification Label

The scanner is classified as a Class 2 laser product according to EN60825-1 regulations and as a Class II laser product according to CDRH regulations.

Disconnect the power supply when opening the device during maintenance or installation to avoid exposure to hazardous laser light.

There is a safety device, which allows the laser to be switched on only if the motor is rotating above the threshold for its correct scanning speed.

The laser beam can be switched off through a software command (see also the Genius™ Help On-Line).





Warning and Device Class Label



Device Identification Label

The laser diodes used in this device are classified as Class 3B laser products according to EN 60825-1 regulations and as Class IIIb laser products according to CDRH regulations. Any violation of the optic parts in particular can cause radiation up to the maximum level of the laser diode (30 mW at 630~680 nm).

FCC COMPLIANCE

Modifications or changes to this equipment without the expressed written approval of Datalogic could void the authority to use the equipment.

This device complies with PART 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference which may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

POWER SUPPLY

This product is intended to be installed by Qualified Personnel only.

- This scanner is intended to be supplied by either a UL Listed power supply marked 'Class 2' or 'LPS', output rated 20 - 30 V dc, minimum 1.5 A or by a UL Listed computer with LPS outputs.
- This scanner must be supplied by a Class II Power Supply Unit conforming to the EN 60950 safety regulation.

CE COMPLIANCE

Warning:
This is a Class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

PATENTS

This product is covered by one or more of the following patents.

U.S. patents: Re. 36,251; 5,992,740; 6,347,740 B1; 6,177,979 B1; 6,394,352 B1; 6,443,360 B1; 6,527,184 B1; 6,629,639 B2; 6,742,710 B2; 7,161,685 B1.

European patents: 652,530 B1; 789,315 B1; 851,376 B1; 926,615 B1; 959,426 B9; 1,217,571 B1; 1,363,228 B1; 1,607,901 B1.

Japanese patents: 3,793,585 B2; 4,033,958 B2; 4,376,353 B2.